



Height Restrictor Barrier Installation Guide

Installing the Barrier

Dig holes to a maximum of 1100mm deep at centres to suit barrier width (1.1m in the ground gives 2.0m height clearance)

Concrete the hanging post into the foundation ensuring the hooks are positioned correctly to achieve desired opening. (Rear hung opening in, Front hung opening out)

Fit the adjustable gate eyes onto the hanging post and position through the barrier hanging stile, hang the barrier.

Concrete the slamming post into the foundation ensuring the padlock box tab is on the correct face.

Adjust the barrier as required to line up with the slamming post, check the padlock secure box fits correctly onto the padlock lug.

Installing the Hold-back posts

Install in the same way as the slam post taking into account any change in ground gradient (foundation depth may need adjusting)

