



## Merlin Vehicle Barrier – Installation Guide

### Installing the Barrier

- Dig holes to a maximum of 800mm deep at centres to suit barrier width
- Concrete the hanging post into the foundation ensuring the hooks are on the back (or front) of the post
- Fit the adjustable gate eyes onto the hanging post and position through the barrier hanging stile, hang the barrier
- Concrete the slamming post into the foundation ensuring the padlock box is on the back (or front) of the post
- Adjust the barrier as required to line up with the slamming post, check the padlock secure box fits correctly onto the padlock lug

### Hold-back posts

- Install in the same way as the slam post taking into account any change in ground gradient (foundation depth may need adjusting)

